

Wood Glider Egress Chart

Wood Glider Egress Chart			
Product	EGRESS OPENING		
	Clear Opening Width (inches)	Clear Opening Height (inches)	Vent Opening (FT ²)
WG 0806	11.879	19.78	1.6
WG 0808	12.379	27.66	2.3
WG 0810	11.879	35.53	2.9
WG 0812	11.879	43.407	3.6
WG 1006	15.816	19.782	2.2
WG 1008	15.816	27.657	3
WG 1010	15.816	36.532	3.9
WG 1012	15.816	43.407	4.8
WG 1206	19.754	19.782	2.7
WG 1208	19.754	27.657	3.8
WG 1210	19.754	35.532	4.9
WG 1212	19.754	43.407	6
WG 1406	23.691	19.782	3.3
WG 1408	23.691	27.657	4.6
WG 1410	23.691	35.532	5.8
WG 1412	23.691	43.407	7.1
WG 1606	27.629	19.782	3.8
WG 1608	27.629	27.657	5.3
WG 1610	27.629	35.532	6.8
WG 1612	27.629	43.407	8.3

Canadian Egress:

- In accordance with the National Building Code of Canada
- Requirements:
 - A. Minimum **3.8 FT²** (0.35m²) of clear opening.
 - B. Minimum **15 inches** (380mm) of clear opening width.
 - C. Minimum **15 inches** (380mm) of clear opening height.

USA Egress:

- In accordance with the International Building Codes
- Requirements:
 - A. Minimum **5.7 FT²** (0.53m²) of clear opening.
 - B. Minimum **20 inches** (508mm) of clear opening width.
 - C. Minimum **24 inches** (610mm) of clear opening height.

Egress codes may vary. Always verify with your code provider.