

FINISHING NORWOOD WINDOWS AND DOORS:

- 1. Lay the window or door horizontally on a flat, dry, clean surface.
- 2. Remove all hardware (hinges, locksets, sweeps, peep holes, kick plates, mail slots, etc...).
- 3. Cover all permanent non-wood components (i.e, glass).
- 4. Sand all wood components lightly with 220 grit sandpaper direction of grain.
- 5. Remove dust with a clean, slightly moistened sponge or cloth.
- 6. Apply a coat of good quality primer and apply as per product's instructions.
- 7. The finish used must be as follows:
 A) Contain ultra-violet protection (for exterior merchandise)
 B) Applied to give at least 2 coats of finish
 C) Applied as instructed by the manufacturer (follow directions carefully)
- 8. Consult a local finishing dealer for the proper finish.
- 9. Test finish on an inconspicuous area before finishing entire door.
- 10. Apply finish to every wood surface of the window and door:
 - A) Includes all 6 surfaces- top, bottom, both side edges, front & back
 - B) Apply several extra coats of finish to the top & bottom of doors to prevent moisture, absorption into the open end grain (helps to resist warpage)
 - C) Prehung units- fully remove all hinges, locksets, sweeps, peep holes, kick plates, mail slots, etc. to completely finish <u>all</u> wood surfaces.
- 11. Exterior after the finish has dried completely, apply a fine bead of sealant around the perimeter of the glass and panels (on exterior side).
- 12. After the finish has dried completely, apply a fine bead of sealant along the top, bottom, & face of all grooves (on exterior side)
- 13. After finish has dried completely, re-install all hardware & hang your new Norwood door.

MAINTENANCE OF NORWOOD DOORS MERCHANDISE:

- 1. Wood- properly finished merchandise may be cleaned using a damp cloth
- 2. Metal parts- use a non-corrosive cleaner
- 4. Norwood doors panels are designed to "float" to accommodate naturally occurring shrinkage
- & expansion panels may be tapped lightly back into place (some re-finishing may be required)
- 5. Doors should be re-finished periodically (consult a local finishing dealer for details)