



How to increase tension on roll up/down screens

- Remove the screen cassette from the window
- With the screen in the rolled position remove the white end cap of the screen cassette, there should be a sticker on the cassette stating what end that the spring is in.
- The spring is attached to the white end cap so do not pull the end cap all the way off.
- Turn the white end cap clockwise to increase the tension.
- Make a couple of turns and replace the end cap.
- Reinstall the screen in the window and test.
- Repeat above if necessary.